

Safety Notice: Finsterwalder Paralock 3



All users of the Paralock 3 must carry out a functional check before the next flight. This is due to several unintentional openings in flight, which are probably due to incorrect operation.

However, in order to rule out a malfunction, a check by the user is necessary. This consists of releasing the swivel lever at a deflection of about 45°. It should then lock automatically.

Correct locking must then be checked by applying counter-pressure.

This function check must be carried out regularly. If the function check is negative, the Paralock must be returned to the manufacturer.

The [Paralock 3 operating instructions](#) must be observed.

In particular, the secure engagement of the swivel lever must be checked immediately before each launch by pushing against the release button.

In addition, the Paralock 3 may only be flown with the additional blocking mechanism activated. This applies to tandem and solo use.

The pilot *must not* unblock the carabiner during flight (except after an emergency parachute deployment).